1. Functions

Display floor and landing call controller.

Output arrival gong and arrival light.

Indicate elevator condition through light emitting diode indicator.

Support display of elevator condition and set functions of light emitting diode indicator.

Support serial communication input of parking and fire fighting.

2. Dimension

Different model has different dimension, it should refer to final drawing provided by technical

